



# Board Station<sup>®</sup> RE

## Student Workbook

---

**© 1992-2009 Mentor Graphics Corporation**  
**All rights reserved.**

This document contains information that is proprietary to Mentor Graphics Corporation. The original recipient of this document may duplicate this document in whole or in part for internal business purposes only, provided that this entire notice appears in all copies. In duplicating any part of this document, the recipient agrees to make every reasonable effort to prevent the unauthorized use and distribution of the proprietary information.

This document is for information and instruction purposes. Mentor Graphics reserves the right to make changes in specifications and other information contained in this publication without prior notice, and the reader should, in all cases, consult Mentor Graphics to determine whether any changes have been made.

The terms and conditions governing the sale and licensing of Mentor Graphics products are set forth in written agreements between Mentor Graphics and its customers. No representation or other affirmation of fact contained in this publication shall be deemed to be a warranty or give rise to any liability of Mentor Graphics whatsoever.

MENTOR GRAPHICS MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

MENTOR GRAPHICS SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATED TO THIS PUBLICATION OR THE INFORMATION CONTAINED IN IT, EVEN IF MENTOR GRAPHICS CORPORATION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### **RESTRICTED RIGHTS LEGEND 03/97**

U.S. Government Restricted Rights. The SOFTWARE and documentation have been developed entirely at private expense and are commercial computer software provided with restricted rights. Use, duplication or disclosure by the U.S. Government or a U.S. Government subcontractor is subject to the restrictions set forth in the license agreement provided with the software pursuant to DFARS 227.7202-3(a) or as set forth in subparagraph (c)(1) and (2) of the Commercial Computer Software - Restricted Rights clause at FAR 52.227-19, as applicable.

**Contractor/manufacturer is:**

Mentor Graphics Corporation  
8005 S.W. Boeckman Road, Wilsonville, Oregon 97070-7777.  
Telephone: 503.685.7000  
Toll-Free Telephone: 800.592.2210  
Website: [www.mentor.com](http://www.mentor.com)  
SupportNet: [supportnet.mentor.com/](http://supportnet.mentor.com/)

Send Feedback on Documentation: [supportnet.mentor.com/user/feedback\\_form.cfm](http://supportnet.mentor.com/user/feedback_form.cfm)

**TRADEMARKS:** The trademarks, logos and service marks ("Marks") used herein are the property of Mentor Graphics Corporation or other third parties. No one is permitted to use these Marks without the prior written consent of Mentor Graphics or the respective third-party owner. The use herein of a third-party Mark is not an attempt to indicate Mentor Graphics as a source of a product, but is intended to indicate a product from, or associated with, a particular third party. A current list of Mentor Graphics' trademarks may be viewed at: [www.mentor.com/terms\\_conditions/trademarks.cfm](http://www.mentor.com/terms_conditions/trademarks.cfm).

**End-User License Agreement:** You can print a copy of the End-User License Agreement from: [www.mentor.com/terms\\_conditions/enduser.cfm](http://www.mentor.com/terms_conditions/enduser.cfm).

# Table of Contents

---

<b>Module 1</b>	
<b>Overview</b> .....	<b>9</b>
Objectives .....	9
What Is Board Station RE? .....	10
Board Station RE Data. ....	11
Invoking Board Station RE From Design Manager. ....	12
Invoking Board Station RE From LAYOUT. ....	18
Invoking Board Station RE From Command Line .....	19
Saving Board Station RE Data. ....	20
Save As/Restore Functionality. ....	25
Data Transfer .....	26
Lab Exercise .....	32
<b>Module 2</b>	
<b>User Interface</b> .....	<b>33</b>
Objectives .....	33
Board Station RE Interface .....	34
Mouse Mapping .....	35
Ways to Execute Commands .....	36
Panning and Zooming .....	42
Other View Commands .....	43
Operational Modes. ....	44
Selection Methods .....	45
Snap Function .....	47
Display Control .....	48
Creating Display Schemes. ....	53
Locating Objects .....	54
Object Properties .....	55
File Viewer .....	58
Printing in Windows .....	59
Printing in UNIX .....	60
Online Help .....	61
SupportNet .....	62
Locating Information .....	63
Service Request .....	65
Lab Exercise .....	66
<b>Module 3</b>	
<b>Placement.</b> .....	<b>67</b>
Objectives .....	67
Place Parts and Cells .....	68
Cross Probing From Design Architect. ....	69

Cross Probing From Board Station RE .....	70
Cross Probing for Placement .....	71
Placement Settings .....	72
Placement Commands .....	74
Protecting Components .....	82
Lab Exercise .....	83
<b>Module 4</b>	
<b>Routing Configuration With CES.....</b>	<b>85</b>
Objectives .....	85
What Is CES? .....	86
DA/BA to Board Station RE Flow Overview .....	87
Required Environment Variable .....	88
Invoking CES From DA/BA .....	89
Activating CES in Board Station LAYOUT and RE .....	90
Invoking CES From Board Station LAYOUT .....	91
Invoking CES From Board Station RE .....	92
Synchronization in DA/BA to Board Station RE Flow .....	93
CES Main Window .....	94
CES Browser .....	95
CES Spreadsheets .....	96
Mechanical Constraints Setup Overview .....	97
Creating a Scheme .....	98
Creating a Net Class .....	99
Setting Up Trace Properties .....	100
Setting Up Via Assignments .....	101
Assigning Nets to a Net Class .....	102
Creating a Clearance Rule .....	103
Setting Up Class to Class Clearances .....	104
Setting Up General Clearances .....	105
Routing Parameters .....	106
Scheme Usage Example .....	111
Lab Exercise .....	112
<b>Module 5</b>	
<b>Interactive Routing.....</b>	<b>113</b>
Objectives .....	113
Interactive Routing Commands .....	114
Choosing a Net to Route .....	116
Plow Modes .....	117
Ways to Add Vias .....	121
Changing Vias .....	125
Additional Routing Commands .....	126
Changing Active Layers .....	137
Highlighting Nets .....	138
Protecting Nets .....	139
Measuring Distance .....	142
Creating Area Fills .....	143

## Table of Contents

---

Setting Area Fills to Dynamically Update . . . . .	148
Plane Shapes As Routing Keepouts . . . . .	149
Converting Plane Shapes to Graphics . . . . .	150
Lab Exercise 1 — Interactive Fanout . . . . .	151
Lab Exercise 2 — Interactive Routing . . . . .	152
Lab Exercise 3 — Plane Shapes . . . . .	153
<b>Module 6</b>	
<b>Automatic Routing . . . . .</b>	<b>155</b>
Objectives . . . . .	155
Auto Route Dialog Box . . . . .	156
Pass Definition . . . . .	157
Creating Route Schemes . . . . .	164
Interrupting the Auto Router . . . . .	166
Auto Route Report . . . . .	167
Auto Route Options . . . . .	168
Mini Status . . . . .	169
Auto Route Status . . . . .	170
Auto Routing Strategies . . . . .	171
Lab Exercise . . . . .	172
<b>Module 7</b>	
<b>Design Rule Check . . . . .</b>	<b>173</b>
Objectives . . . . .	173
Placement Online DRC Options . . . . .	174
Review Online DRC Hazards . . . . .	175
Batch DRC . . . . .	176
Review Batch DRC Hazards . . . . .	179
Hazard Report . . . . .	180
Locating Hazards . . . . .	181
Disconnecting a Pad Entry . . . . .	182
DRC Windows . . . . .	183
Lab Exercise . . . . .	184
<b>Module 8</b>	
<b>Signal Integrity Routing . . . . .</b>	<b>185</b>
Objectives . . . . .	185
Review . . . . .	186
Net Topology . . . . .	191
Setting Up Custom Topologies (From-Tos) . . . . .	193
Netline Manipulation . . . . .	194
Virtual Pins . . . . .	195
Delays and Lengths . . . . .	196
Matched Length . . . . .	198
Differential Pairs . . . . .	201
Parallelism Rules . . . . .	206
Parallelism . . . . .	208
Stub Length . . . . .	209

Via Count . . . . .	210
Delay Formulas . . . . .	211
Creating Pin-Pairs . . . . .	212
Pin-Pair Versus From-To . . . . .	213
Delay Formulas . . . . .	214
Setting Up Delay Formulas . . . . .	215
Delay Formula Examples . . . . .	216
Delay Formula Constants . . . . .	217
Delay Formulas — Behavior . . . . .	218
Signal Integrity Routing Strategy . . . . .	219
Lab Exercise . . . . .	220
<b>Module 9</b>	
<b>Microvias . . . . .</b>	<b>221</b>
Objectives . . . . .	221
Microvias . . . . .	222
What Is a Microvia Design? . . . . .	223
Layer Stackup Definitions . . . . .	224
Via Span Display . . . . .	225
Microvia Clearances . . . . .	226
Microvias per Net Class . . . . .	228
Via Under Pad Consideration . . . . .	229
Auto Routing Strategies . . . . .	230
Interactive Microvias . . . . .	231
Routing Tips . . . . .	232
Lab Exercise . . . . .	233
<b>Appendix A</b>	
<b>Routing Configuration . . . . .</b>	<b>235</b>
Objectives . . . . .	235
Creating Net Classes . . . . .	236
Creating Clearances Rules . . . . .	237
Setting Net Class to Class Rules . . . . .	238
Assigning Nets to Net Classes . . . . .	239
Creating an Active Scheme . . . . .	240
Routing Parameters . . . . .	241
Scheme Usage Example . . . . .	246
Lab Exercise . . . . .	247
<b>Appendix B</b>	
<b>Signal Integrity Routing . . . . .</b>	<b>249</b>
Objectives . . . . .	249
Review . . . . .	250
Net Order . . . . .	255
Netline Manipulation . . . . .	257
Virtual Pins . . . . .	258
Maximum Length . . . . .	259
Matched Length . . . . .	260

## Table of Contents

---

Editor Control — Tuning . . . . .	261
Differential Pairs . . . . .	262
Parallelism . . . . .	263
Stub Length . . . . .	264
Via Count . . . . .	265
Delay Formulas . . . . .	266
Delay Formulas — Source and Cell References . . . . .	269
Delay Formulas — Non-Source “From” and Variables . . . . .	270
Delay Formulas — Examples . . . . .	271
Delay Formulas — Behavior . . . . .	272
Delay Formulas . . . . .	273
Signal Integrity Routing Strategy . . . . .	274
Lab Exercise . . . . .	275
<b>Appendix C</b>	
<b>Jumpers . . . . .</b>	<b>277</b>
Objectives . . . . .	277
Jumper Functionality . . . . .	278
Define Default Jumper for Board Station . . . . .	279
Define Jumper Geometry for Board Station RE . . . . .	280
Placing Jumpers in LAYOUT . . . . .	281
Invoking Board Station RE . . . . .	282
Editor Control — Jumper Tab . . . . .	283
Placing the Jumper and Plow Routing . . . . .	284
Modify Jumper Location or Pin Spacing . . . . .	285
Restricting Jumpers in Board Station RE . . . . .	286

